

226 Bed Assembly Instructions

Please note that this assembly requires 2 people

Step 1: Lay the footboard and side rails upside down on the floor on a blanket, so the finish is not damaged.

Step 2: Ensure that there are 10 bolts and a hex key.

Step 3: Attach the corner block to the footboard with the bolt and hex key provided, **do not tighten fully**. Do this on both ends of the footboard.

Step 4: Line up one side rail to the footboard, using the provided bolt insert into the slot in the side rail and screw it into the footboard with the hex key. Fully tighten this bolt and the corner block bolt into the footboard.

Step 5: Repeat steps 3 & 4 on the other side of the footboard.

Step 6: With the help of another person flip the footboard and side rails over so they are face up. Do this by lifting **with 2 hands** on the side rail and rotating 180 degrees taking care not to twist the joint between the side rail and the footboard.

Step 7: Line up the side rail to the inserts on one side of the headboard. Insert one bolt from the back of the headboard into the side rail in either of the 2 holes, **do not tighten fully**.

Step 8: Repeat on the other side of the headboard and attach the side rail to the headboard, **do not tighten fully**.

Step 9: Insert the second bolt to attach the headboard to the side rail, tighten both of these bolts and repeat on the other side of the headboard.

Step 10: Screw 3 center feet into the center beam. Place the center support beam between the headboard and foot. Start by inserting the headboard end first to avoid marking the headboard with the center beam.

Step 11: Roll out the slat roll package across the bed opening.

